

Hamshack Hotline (HH) Aastra 9133i Experimental Server (HHUX)



Model 9133i
IP Telephone

Access phone web UI

The screenshot shows a web browser window with the address bar displaying `192.168.1.147`. The browser's address bar also shows navigation icons (back, forward, home) and security icons (lock, shield, star). The browser's title bar includes window control icons (minimize, maximize, close) and a system tray icon.

The background page is the AMSTRA phone web UI. The top left corner features the AMSTRA logo. The top right corner displays the phone number `9133i` and a `Log Off` link. The main content area is partially obscured by a modal dialog box. The visible text on the page includes:

- Status**
 - System Information
- Operation**
 - User Password
 - Programmable Keys
 - Directory
 - Reset
- Basic Settings**
 - Preferences
 - Call Forward
- Advanced Settings**
 - Network
 - Global SIP
 - Line 1
 - Line 2
 - Line 3
 - Line 4
 - Line 5
 - Line 6
 - Line 7
 - Line 8
 - Line 9
 - Action URI
 - Configuration Server
 - Firmware Update
 - Troubleshooting

The modal dialog box is titled "http://192.168.1.147 is requesting your username and password. The site says: 'Please enter User name and password'". It contains two input fields: "User Name:" with the text `admin|` and "Password:" with masked characters `.....` and the text `22222`. The dialog box has "Cancel" and "OK" buttons.

Overlaid on the background page is a "Session Expired" message that reads: "Session Expired. Please close the browser. [Log In](#)".

Preferences

← → ↻ 🏠 192.168.1.147/preferences.html ... 🛡️ ☆

AMSTRA 9133i
Log Off

Status
System Information

Operation
User Password
Programmable Keys
Directory
Reset

Basic Settings
Preferences
Call Forward

Advanced Settings
Network
Global SIP
Line 1
Line 2
Line 3
Line 4
Line 5
Line 6
Line 7
Line 8
Line 9
Action URI
Configuration Server
Firmware Update
Troubleshooting

Preferences

General

Idle Display Name 1	<input type="text" value="Clint W2BL"/>
Idle Display Name 2	<input type="text" value="HHUX 55123"/>
Local Dial Plan	<input type="text" value="x+#[xx+*"/>
Send Dial Plan Terminator	<input type="checkbox"/> Enabled
Digit Timeout (seconds)	<input type="text" value="4"/>
Suppress DTMF Playback	<input type="checkbox"/> Enabled
Play Call Waiting Tone	<input checked="" type="checkbox"/> Enabled
Stuttered Dial Tone	<input checked="" type="checkbox"/> Enabled
XML Beep Support	<input checked="" type="checkbox"/> Enabled
Status Scroll Delay (seconds)	<input type="text" value="5"/>
Incoming Call Interrupts Dialing	<input type="checkbox"/> Enabled
Goodbye Key Cancels Incoming Call	<input checked="" type="checkbox"/> Enabled

Incoming Intercom Settings

Microphone Mute	<input checked="" type="checkbox"/> Enabled
Auto-Answer	<input checked="" type="checkbox"/> Enabled
Allow Barge In	<input checked="" type="checkbox"/> Enabled

Key Mapping

Map Redial Key To	<input type="text"/>
Map Conf Key To	<input type="text"/>

Network Settings

Network Settings

Basic Network Settings

DHCP	<input checked="" type="checkbox"/> Enabled
IP Address	<input type="text" value="192.168.1.147"/>
Subnet Mask	<input type="text" value="255.255.255.0"/>
Gateway	<input type="text" value="192.168.1.1"/>
Primary DNS	<input type="text" value="192.168.1.1"/>
Secondary DNS	<input type="text" value="0.0.0.0"/>

Advanced Network Settings

NAT IP	<input type="text"/>
NAT Port	<input type="text" value="0"/>
Nortel NAT Traversal Enabled	<input type="text" value="No"/> ▼
Nortel NAT Timer (seconds)	<input type="text" value="60"/>
NTP Time Servers	<input checked="" type="checkbox"/> Enabled
Time Server 1	<input type="text" value="129.6.15.28"/>
Time Server 2	<input type="text" value="0.0.0.0"/>
Time Server 3	<input type="text" value="0.0.0.0"/>

Global SIP Settings

Global SIP Settings

Basic SIP Authentication Settings

Screen Name	<input type="text" value="W2BL"/>
Phone Number	<input type="text" value="55123"/>
Caller ID	<input type="text" value="55123"/>
Authentication Name	<input type="text" value="55123"/>
Password	<input type="password" value="*****"/>
BLA Number	<input type="text"/>
Line Mode	<input type="text" value="Generic"/>

Basic SIP Network Settings

Proxy Server	<input type="text" value="hhux.hamshackhotline.com:5160"/>
Proxy Port	<input type="text" value="5160"/>
Backup Proxy Server	<input type="text" value="0.0.0.0"/>
Backup Proxy Port	<input type="text" value="0"/>
Outbound Proxy Server	<input type="text" value="0"/>
Outbound Proxy Port	<input type="text" value="0"/>
Registrar Server	<input type="text" value="hhux.hamshackhotline.com:5160"/>
Registrar Port	<input type="text" value="5160"/>
Backup Registrar Server	<input type="text" value="0.0.0.0"/>
Backup Registrar Port	<input type="text" value="0"/>
Registration Period	<input type="text" value="3700"/>

Configuration Line 1

Configuration Line 1

Basic SIP Authentication Settings

Screen Name	<input type="text" value="W2BL"/>
Phone Number	<input type="text" value="55123"/>
Caller ID	<input type="text" value="55123"/>
Authentication Name	<input type="text" value="55123"/>
Password	<input type="password" value="....."/>
BLA Number	<input type="text"/>
Line Mode	<input type="text" value="Generic"/>

Basic SIP Network Settings

Proxy Server	<input type="text" value="hhux.hamshackhotline.com:5160"/>
Proxy Port	<input type="text" value="5160"/>
Backup Proxy Server	<input type="text" value="0.0.0.0"/>
Backup Proxy Port	<input type="text" value="0"/>
Outbound Proxy Server	<input type="text" value="0"/>
Outbound Proxy Port	<input type="text" value="0"/>
Registrar Server	<input type="text" value="hhux.hamshackhotline.com:5160"/>
Registrar Port	<input type="text" value="5160"/>
Backup Registrar Server	<input type="text" value="0.0.0.0"/>
Backup Registrar Port	<input type="text" value="0"/>
Registration Period	<input type="text" value="3700"/>

Resources

- Aastra 9133i User / Admin guides and firmware
 - <https://www.mitel.com/open-solutions/9133i>
- HHUX SIP/Proxy Server
 - hhux.hamshackhotline.com:5160